EVAPO-RUST™

Non-harmful rust remover

PERFORMANCE

Rapidly removes rust from ferrous metal and stainless steel.

Non-corrosive, non-flammable, non-toxic

Biodegradable, Contains no VOC's or HAP's

Contains no solvents, acids, bases or hazardous ingredients

Works at room temperature, requires no special equipment

Easy and safe to use

Safe on soft metals, plastic, rubber, PVC and other surfaces unharmed by water alone
Inhibits rust from reforming for up to 4 weeks

Will not pit or discolor un-rusted steel

Patent Pending

DESCRIPTION

EVAPO-RUSTTM has been proven effective to remove even deep rust on all types of mild steel and iron. It is safe on all surfaces and will not harm copper, brass, aluminum, plastic, rubber or vinyl. **EVAPO-RUST**TM is non-toxic, non-corrosive, biodegradable and contains no acids or alkalis. It is non-flammable and contains no petroleum solvents.

DIRECTIONS

Pre-clean item to remove oil and dirt. Rinse item and immerse item fully in **EVAPO-RUST**[™] for 20 minutes. Check progress periodically. Once rust is removed, rinse item with water. To prevent re-rusting simply dip the item back in **EVAPO-RUST**[™] solution and allow to dry. Deeply rusted parts (5mm or deeper) may require overnight soaking. **EVAPO-RUST**[™] can be used over and over until performance drops off. When ready to dispose of spent **EVAPO-RUST**[™], only the iron content of the solution will dictate disposal method. In most cases, it can be safely put down the drain.

PROPERTIES

Appearance Yellow liquid Odor Slight odor Foam Slight @ 1% 6.0-7.1

Environmental Data Biodegradable, Iron content dictates disposal method

Packaging 1 gallon jugs 4X1 gallon cases 5 gallon pails 55 gallon drums

HMIS

HYPERLINK "http://WWW.EVAPO-RUST.COM" <u>WWW.EVAPO-RUST.COM</u> 1-888-329-9877 • 1-479-756-9877 • Fax 1-479-927-3202 P.O. Box 6487 • Springdale, AR 72766 •USA • HILabs@arkansas.net